



**TRP Communications, Inc.**

**TRP**

TRP Communications, Inc.

5309 Millcreek Boulevard

Brunswick, Ohio 44212

Phone: 330-273-5666

Fax: 330-273-5666

Email: [Support@TRPComm.com](mailto:Support@TRPComm.com)

Website: <http://www.TRPComm.com>

## Technical Information

**Date: April 2, 2014**

**Document No: TN-PS040214**

**Title: Changing the ring tone on your Panasonic digital/VoIP telephone**

### SUMMARY

Panasonic considers ring tone for internal intercom and incoming telephone lines as two different programmable call paths. This means if you want intercom and outside lines to have different ring tones you will need to program them separately. You must program the change in ring tone for each separate line (LINE 1, LINE 2, LINE 3, or CALL 1, CALL 2, CALL 3, etc.) as needed. The instructions below vary slightly based on the type of Panasonic telephone to be programmed.

### INSTRUCTIONS

1. Handset in cradle.
2. Press the PROG or PROGRAM or PAUSE button
3. Press LINE 1 or CALL 1 button TWICE
4. Display will show the current ring tone name currently selected
5. Use the up and down arrows on the cursor pad to highlight and listen to the ring tone options
6. With a specific ring tone highlight, press AUTO DIAL/STORE button
7. Press PROG or PAUSE button to end

NOTE: Repeat this process for each LINE or CALL button on the phone as needed. If you want to change the INTERCOM ring tone, press the INTERCOM button twice (rather than a specific LINE button) on instruction line #4 above.